



Quick reference tuning guide

NORTH SAILS



True Wind Speed	Cap tension	Turns *	mm	Lower tension	Turns *	mm	Genoa Car	Sheet off spr	Main Trav
0-5	15	-4		12	-5		-1	3-4"	UP all the way
6-9	16	-3		13	-4		N	2-3"	Down 50mm
10-13 (Base)	19	0		17	0		N	2-4"	Down 70mm
14-17	22	+3		19	+2		+1-2	4-6"	Middle
19+	25	+6		26	+6		N	6-8"	50-70mm Below CL
Knots	Loos PT-2	* Turns from base (check for your boat)	Calibration (measure thread distance on your boat)	Loos PT-2	* Turns from base (check for your boat)	Calibration (measure thread distance on your boat)	From Neutral	Add 1-2" for choppy water	Measure from Windward end of track.

Notes:

Dock rig measurement position - measure rig with backstay slack

For more information about North Sails on your Etchells please contact your local representative:

office@au.northsails.com

Sydney (02) 9998 8500 - Julian Plante

Melbourne (03) 9534-0363 - Ross Lloyd

Brisbane (07) 3883-3464 - Vaughan Prentice

Updated July 2006